



CANAL 01	BOMBO	AKG D-112
CANAL 02	CAIXA (A DALT)	SHURE SM-57
CANAL 03	CAIXA (A BAIX)	SHURE SM-57
CANAL 04	TOM	SHURE SM-57
CANAL 05	FLOOR TOM	SHURE SM-57
CANAL 06	HI HAT	AKG C-451 B
CANAL 07	AMBIENT L	AKG C-451 B
CANAL 08	AMBIENT R	AKG C-451 B
CANAL 09	TOM 1 (PERC)	SHURE SM-57
CANAL 10	TOM 2 (PERC)	SHURE SM-57
CANAL 11	AMBIENT (PERC)	AKG C-451 B
CANAL 12	ROLAND SPD SX L	D.I.
CANAL 13	ROLAND SPD SX R	D.I.
CANAL 14	TECLAT	D.I.
CANAL 15	GUIARRA ELÈCTRICA	SHURE SM-57
CANAL 16	GUIARRA ELÈCTRICA	SHURE SM-57
CANAL 17	GUIARRA ACÚSTICA	D.I.
CANAL 18	BAIX (LÍNIA)	D.I.
CANAL 19	BAIX (MIC)	SENNHEISER 421
CANAL 20	MIC KAZOO	SENNHEISER E606
CANAL 21	VEU	SHURE SM-58
CANAL 22	VEU	SHURE SM-58
CANAL 23	VEU	SHURE SM-58
CANAL 24	VEU	SHURE SM-58
CANAL 25	VEU	SHURE SM-58
CANAL 26	VEU	SHURE SM-58

AUX 01	FLOOR GUITAR 1
AUX 02	FLOOR GUITAR
AUX 03	FLOOR VEUS2
AUX 04	FLOOR BASS
AUX 05	FLOOR DRUMS
AUX 06	FLOOR PERC
AUX 07	IN-EAR (MONO)
AUX 08	IN-EAR (STEREO R)
AUX 09	IN-EAR (STEREO L)
AUX 10	IN-EAR (MONO)

NECESSITATS

MIDA MÍNIMA D'ESCENARI: 6 X 4 METRES

CORRENT: 6 PUNTS DE CORRENT 220 V (⚡)

AUXILIARS: MÍNIM DE 6 MONITORS AMB 10 ENVIAMENTS INDEPENDENTS